


DEZURIK CYLINDER OPERATED G-SERIES ACTUATOR USED ON PEC ECCENTRIC VALVES



Instruction **D10022**
August 2012

Instructions

These instructions are for use by personnel who are responsible for the installation, operation and maintenance of DeZURIK valves, actuators or accessories.

Safety Messages

All safety messages in the instructions are identified by a general warning sign and the signal word CAUTION, WARNING or DANGER. These messages indicate procedures to avoid injury or death.

Safety label(s) on the product indicate hazards that can cause injury or death. If a safety label becomes difficult to see or read, or if a label has been removed, please contact DeZURIK for replacement label(s).

⚠WARNING

Personnel involved in the installation or maintenance of valves should be constantly alert to potential emission of pipeline material and take appropriate safety precautions. Always wear suitable protection when dealing with hazardous pipeline materials. Handle valves which have been removed from service with suitable protection for any potential pipeline material in the valve.

Inspection

Your DeZURIK product has been packaged to provide protection during shipment; however, items can be damaged in transport. Carefully inspect the unit for damage upon arrival and file a claim with the carrier if damage is apparent.

Parts

Replaceable wear parts are listed on the assembly drawing. These parts can be stocked to minimize downtime. Order parts from your local DeZURIK sales representative or directly from DeZURIK. When ordering parts please provide the following information:

If the valve has a data plate: please include the 7-digit part number with either 4-digit revision number (example: 9999999R000) or 8-digit serial number (example: S1900001) whichever is applicable. The data plate will be attached to the valve assembly. Also, include the part name, the assembly drawing number, the balloon number and the quantity stated on the assembly drawing.

If there isn't any data plate visible on the valve: please include valve model number, part name, and item number from the assembly drawing. You may contact your local DeZURIK Representative to help you identify your valve.

DeZURIK Service

DeZURIK service personnel are available to maintain and repair all DeZURIK products. DeZURIK also offers customized training programs and consultation services. For more information, contact your local DeZURIK sales representative or visit our website at DeZURIK.com.

Table of Contents

Description - - - - -	4
Air Supply - - - - -	4
Lubrication - - - - -	4
Actuator Identification - - - - -	4
Adjusting Position Stops	
<i>Adjusting the Open Position Stop</i> - - - - -	5
<i>Adjusting the Closed Position Stop</i> - - - - -	6
Removing Actuator - - - - -	9
Installing Actuator - - - - -	10
Removing Cylinder - - - - -	11
Installing Cylinder - - - - -	11
Disassembling Actuator - - - - -	13
Reassembling Actuator - - - - -	14
Changing Mounting Positions - - - - -	16
<i>Mounting Actuator in 60° Increments on 4–20" (100–500mm) Valves and 90°</i>	
<i>Increments on 24–36" (600–900mm) Valves</i> - - - - -	16
<i>Mounting Actuator in 30° Increments on 4–20" (100–500mm) Valves Only</i> - - - - -	16
<i>Mounting Actuator in 45° Increments on 24–36" (600–900mm) Valves Only</i> - - - - -	17
Troubleshooting - - - - -	18

DeZURIK

Cylinder Operated G-Series Actuator

Description

The G-Series Cylinder Actuator is a totally enclosed, quarter turn, pneumatic operated actuator. A 2" (50mm) square nut on top of the actuator is provided for manual operation. It is supplied with a single cylinder, and single or double booster cylinders dependent on application.

Air Supply

The supply pressure to the cylinder should be between 50 and 100 psi (344 and 689 kPa).

Lubrication

The G-Series Cylinder Actuator has been lubricated at the factory and requires no routine lubrication. If the actuator is disassembled, lubricate the rack, rack guide, gear sector and bearings using one of these lubricants:

- Keystone Zeniplex-1 (**recommended**)
- Amoco Amolith Grease #1-EP (alternate)
- Amsoil GHD (alternate)
- Mobil Mobilux EP 1 (alternate)
- Petro-Canada Vultrex MPG EP 1 (alternate)
- Shell Alvania EP 1 (alternate)
- Texaco Multifak EP 1 (alternate)

If the cylinder is disassembled, it must be lubricated as described in the cylinder instructions.

Actuator Identification

The G-Series Cylinder Actuator is available in three sizes: G6, G12 and G16. See Figure 1 for actuator identification.




Figure 1 - Actuator Identification

To determine the actuator size, measure the diameter of the cover - see Figure 1 and Table A. To determine the cylinder size, measure the diameter of the cylinder - see Figure 1 and Table B.

Table A: Actuator Identification

Actuator	Ø "A"	
	IN	MM
G6	8	205
G12	15	390
G16	19	485

Table B: Cylinder Identification

Cylinder	Ø "B"	
	IN	MM
C4	4.5	115
C6	6.5	165
C8	8.5	215
C10	10.5	265
C12	12.5	320

Adjusting Position Stops

The G-Series Cylinder Actuators have both open and closed position stops. See Figure 2 for position stop identification.




Figure 2 – Position Stops

The position stops are factory set and do not require adjustment unless the actuator has been disassembled or actuator orientation has been changed.

Adjusting the Open Position Stop

On actuators without booster cylinders, the open position stop is located in the end of the extension cap opposite the cylinder. On actuators with booster cylinders, the open position stop is located in the end of the power cylinder. See Figure 2.

1. Open the valve and loosen the Open Position jam nut.
2. Adjust the Open Position set screw to the proper position.
3. Lock the Open Position set screw in place with the jam nut.

Adjusting Position Stops *(Continued)*

Adjusting Closed Position Stop

On actuators without booster cylinders, the closed position stop is located in the end of the cylinder. On actuators with booster cylinders, the closed position stop is located in the end of the booster cylinder. See Figure 2.

Valves can be mounted with Direct or Reverse pressure.

Direct Pressure - When the higher pressure is at the end opposite the seat. See Figure 3.

Reverse Pressure - When the higher pressure is at the seat end of the valve. See Figure 3.




Figure 3 – Pressure Direction

1. Discontinue flow and relieve pipeline pressure.
2. Back out the Closed Position set screw about 1½ turns.
3. Close the valve with the pressure specified in Table C and Table D for the appropriate size and pressure direction—See Figure 3.

Direct Pressure (higher pressure is at end opposite the seat), use the cylinder pressure specified in Table C and Table D for 25 psi (172 kPa) reverse pressure drop.

Reverse Pressure (higher pressure is at seat end of valve), use the cylinder pressure specified in Table C and Table D for the amount of reverse pressure drop in your pipeline.

The pressure in Table C and Table D will provide tight shut off or minimum leakage (depending on pressure drop) with maximum plug life. If the reverse pressure drop in the pipeline is unknown, set closing pressure for the maximum pressure drop. Reset the closing pressure as soon as actual pressure drop can be determined because the maximum setting decreases plug life.

4. Maintain pressure for 5 minutes to allow the plug to seat, then tighten the set screw in until it comes into contact with the piston rod.

NOTE: Make sure the thread seal is positioned properly, and lock the setscrew in place with the jam nut.

Adjusting Position Stops *(Continued)*

Table C: Cylinder Closing Pressure - Reverse Pressure Drop*

Valve Size	Actuator & Cylinder	Cylinder Closing Pressure (For Direct Pressure Drop Use Same as 25# Reverse)									
		25 psi	172 kPa	50 psi	344 kPa	75 psi	517 kPa	100 psi	689 kPa	125 psi	861 kPa
4" (100mm)	G6-C4	14	96	15	103	16	110	17	117	18	124
	G6-C6	7	48	7	48	8	55	9	62	9	62
6" (150mm)	G6-C4	21	144	24	165	27	186	31	213	32	220
	G6-C6	10	68	11	75	12	82	13	89	14	96
8" (200mm)	G6-C6	20	137	22	151	25	172	28	193	—	—
	G6-C8	11	75	13	89	15	103	16	110	—	—
	G12-C6	10	68	11	75	13	89	14	96	15	103
	G12-C8	6	41	7	48	8	55	8	55	9	62
10" (250mm)	G6-C6	30	206	36	248	—	—	—	—	—	—
	G6-C8	17	117	20	137	—	—	—	—	—	—
	G12-C6	15	103	18	124	21	144	24	165	26	179
	G12-C8	9	62	10	68	12	82	14	96	15	103
	G12-C10	6	41	7	48	8	55	9	62	10	68
12" (300mm)	G6-C6	41	282	—	—	—	—	—	—	—	—
	G6-C8	23	158	—	—	—	—	—	—	—	—
	G12-C6	21	144	26	179	30	206	35	241	—	—
	G12-C8	12	82	15	103	17	117	20	137	22	151
	G12-C10	8	55	10	68	11	75	13	89	14	96
	G16-C8	9	62	11	75	13	89	15	103	17	117
	G16-C10	6	41	7	48	8	55	10	68	11	75
	G16-C12	4	27	5	34	6	41	7	48	8	55
14" (350mm)	G12-C6	26	179	34	234	—	—	—	—	—	—
	G12-C8	15	103	19	131	24	165	28	193	—	—
	G12-C10	10	68	13	89	15	103	18	124	—	—
	G16-C8	11	75	15	103	18	124	21	144	—	—
	G16-C10	7	48	10	68	12	82	14	96	—	—
	G16-C12	5	34	7	48	8	55	10	68	—	—
	G16-C10B10	8	55	11	75	13	89	15	103	—	—
16" (400mm)	G12-C6	32	220	—	—	—	—	—	—	—	—
	G12-C8	18	124	24	165	—	—	—	—	—	—
	G12-C10	12	82	16	110	19	131	—	—	—	—
	G16-C8	14	96	18	124	22	151	26	179	—	—
	G16-C10	9	62	12	82	15	103	17	117	—	—
	G16-C12	6	41	8	55	10	68	12	82	—	—
	G16-C10B10	10	68	13	89	16	110	18	124	—	—
	G16-C10B12	7	48	10	68	12	82	14	96	—	—

* Reverse Pressure Drop: The pressures specified for reverse pressure drop will provide tight pressure shutoff or minimum leakage with maximum plug life.

If a dead-tight shutoff with reverse pressure is required, contact DeZURIK

DeZURIK

Cylinder Operated G-Series Actuator

Adjusting Position Stops *(Continued)*

Table D: Cylinder Closing Pressure - Reverse Pressure Drop*

Valve Size	Actuator & Cylinder	Cylinder Closing Pressure (For Direct Pressure Drop Use Same as 25# Reverse)							
		25 psi	172 kPa	50 psi	344 kPa	75 psi	517 kPa	100 psi	689 kPa
18" (450mm)	G12-C6	37	255	—	—	—	—	—	—
	G12-C8	21	144	29	199	—	—	—	—
	G12-C10	14	96	19	131	—	—	—	—
	G16-C8	16	110	22	151	28	193	33	227
	G16-C10	10	68	14	96	18	124	21	144
	G16-C12	7	48	10	68	12	82	15	103
	G16-C10B10	11	75	15	103	19	131	22	151
	G16-C10B12	8	55	11	75	13	89	16	110
	G16-C12B12	8	55	11	75	13	89	16	110
20" (500mm)	G16-C12B10B10	12	82	16	110	20	137	23	158
	G12-C8	24	165	34	234	—	—	—	—
	G12-C10	15	103	22	151	—	—	—	—
	G16-C8	18	124	25	172	32	220	39	268
	G16-C10	12	82	16	110	21	144	25	172
	G16-C12	8	55	12	82	15	103	18	124
	G16-C10B10	13	89	17	117	22	151	26	179
	G16-C10B12	9	62	13	89	16	110	19	131
	G16-C12B12	9	62	13	89	16	110	19	131
24" (600mm)	G16-C12B10B10	14	96	18	124	23	158	27	186
	G16-C8	22	151	38	262	—	—	—	—
	G16-C10	14	96	21	144	28	193	34	234
	G16-C12	10	68	15	103	19	131	24	165
	G16-C10B10	15	103	22	151	29	199	35	241
	G16-C10B12	11	75	16	110	20	137	25	172
	G16-C12B12	11	75	16	110	20	137	25	172
	G16-C12B10B10	16	110	23	158	30	206	36	248
30" (750mm)	G16-C12B12B12	12	82	17	117	21	144	26	179
	G16-C8	28	193	—	—	—	—	—	—
	G16-C10	18	124	29	199	—	—	—	—
	G16-C12	13	89	20	137	27	186	34	234
	G16-C10B10	19	131	30	206	40	275	50	344
	G16-C10B12	14	96	21	144	28	193	35	241
	G16-C12B12	14	96	21	144	28	193	35	241
	G16-C12B10B10	20	137	31	213	41	282	51	351
36" (900mm)	G16-C12B12B12	15	103	22	151	29	199	36	248
	G16-C10B12	56	386	—	—	—	—	—	—
	G16-C12B12	39	268	50	344	—	—	—	—
	G16-C12B10B10	39	268	50	344	—	—	—	—
36" (900mm)	G16-C12B12B12	39	268	50	344	—	—	—	—

* Reverse Pressure Drop: The pressures specified for reverse pressure drop will provide tight pressure shutoff or minimum leakage with maximum plug life.

If a dead-tight shutoff with reverse pressure is required, contact DeZURIK

Removing Actuator

When eccentric valves are mounted in a vertical pipeline, or mounted in a horizontal pipeline with the plug stem horizontal, gravity can cause the plug to swing to a lower position in the valve body when the actuator is removed. To avoid this problem, place the plug in the lowest position before removing the actuator.

1. Discontinue flow, relieve pipeline pressure and close valve.



WARNING!

Accidental operation of power actuator can cause personal injury or equipment damage. Disconnect and lock out power to actuator before servicing.

2. Disconnect and lock out the pneumatic power to prevent accidental operation of the actuator.
3. Scribe corresponding lines on the valve and actuator to help align them during installation.
4. If the valve is **4–20" (100–500mm)**, remove the lock nut, spring washers, wrenching nut and pointer from the plug stud, then go to step 6.
5. If the valve is **24–36" (600–900mm)**, follow the steps below.
 - a. Loosen the #1 lockscrews about 6 to 8 turns. Loosen the #2 lockscrews about 3 turns. See Figure 4




Figure 4 – 24-36" Valve Key and Lockscrew Arrangement

- b. Using a soft hammer, tap the heads of the #1 lockscrews to loosen the keys.
 - c. Remove the four screws holding the wrenching nut to the gear sector, then remove the stud locknut, spring washers and the wrenching nut with the keys attached. Continue with step 6.

Removing Actuator *(Continued)*



WARNING!

This valve is a pressure vessel. On 4, 5, 6 and 10" (100, 125, 150 and 250mm) valves, the same bolts hold both the actuator and the bonnet.

Removing the bolts on 4, 5, 6 and 10" (100, 125, 150 and 250mm) valves before relieving pipeline pressure can result in personal injury or equipment damage.

Always relieve pipeline pressure before removing the actuator.

6. Remove the screws fastening the adapter to the valve. On the **4, 5, 6 and 10" (100, 125, 150 and 250mm)** valves, these screws also hold the bonnet to the valve body.
7. Lift the actuator and adapter off the valve.

Installing Actuator

1. Place the valve in the position it was in when the actuator was removed.
NOTE: Normally this will be so the plug is in the lowest position in the valve body.
2. Line up the scribe marks on the valve and actuator made during actuator removal, then set the actuator on the valve so that the valve shaft slides into the actuator gear sector.
3. Fasten the actuator adapter to the valve.
4. Slide the pointer and wrenching nut down the plug stud so that it rests on top of the gear sector; the pointer should point to the correct valve position. If the valve is **24–36" (600–900mm)**, hold the keys in position when you slide the wrenching nut over the plug stud and guide the keys into the gear sector and stem slots. Then install the four screws fastening the wrenching nut to the gear sector.
5. Place the spring washers on the plug stud as shown in Figure 5.




Figure 5 – Spring Washer Detail

6. Screw the lock nut down the plug stud until it is tight and the spring washers are completely compressed, then back the nut off one full turn.
7. If the valve is **24–36" (600–900mm)**, tighten the #2 lockscrews and then the #1 lockscrews to hold the keys in place; if the valve is **4–20" (100–500mm)**, go to step 8. See Figure 4

Removing Cylinder

This procedure can be performed with the actuator installed on the valve or removed.

1. Discontinue flow and relieve pipeline pressure.
2. Apply air pressure to the port in the cylinder cap (the end farthest from the actuator housing) until the valve has moved to the end of its stroke.



WARNING!

**Accidental operation of power actuator can cause personal injury or equipment damage.
Disconnect and lock out power to actuator before servicing.**

3. Disconnect and lock out the pneumatic power to prevent accidental operation of the actuator.
4. Disconnect the tubing from both cylinder ports.
5. Remove the extension cap from the actuator housing. On units with booster cylinders, carefully remove the booster cylinder or cylinders.
6. Remove the nuts and spring washers from the end of the rack rod.
7. Remove the screws or nuts fastening the cylinder assembly to the housing, and carefully remove the cylinder assembly by sliding it away from the actuator until the rack rod clears the actuator housing.
8. See cylinder instructions for details on rebuilding the cylinder.

Installing Cylinder

1. Scrape the old gasket material from the actuator housing and cylinder head, then place a new gasket on the cylinder head.
2. Install the cylinder/rack rod assembly by sliding the rack rod through the rack then fasten the cylinder to the housing.
Note: If the rack rod is not attached to the cylinder, clean the threads of both the rack rod and the cylinder shaft, then apply Loctite to the cylinder shaft threads, and screw the rack rod onto the cylinder shaft.
3. Slide the spacer, spring washers and nuts onto the rack rod. See Table E for arrangement of spring washers.
4. Screw one nut onto the rack rod. Screw the nut down until the spring washers are completely compressed, then back the nut off until the washers return to their normal shape.
5. Screw the other nut onto the rack rod and tighten the two nuts against each other.
6. Replace the extension cap. On units with booster cylinders, replace the booster cylinder or cylinders.
7. Reconnect power to the actuator.
8. Adjust the position stops as described in the “*Position Stop*” section.


DeZURIK

Cylinder Operated G-Series Actuator


Installing Cylinder *(Continued)*

Table E: Rack Rod Spring Washer Arrangement


Valve Size		Actuator Size	Direct Pressure	Reverse Pressure
in	mm			
4	100	ALL	A	A
5	125	ALL	B	B
6	150	ALL	B	B
8	200	G6	B	B
		G12	A	A
10	250	G6	B	B
		G12	A	B
12	300	G6	B	B
		G12	B	B
		G16	A	A
14	350	G12	B	B
		G16	A	A
16	400	ALL	B	B
18	450	ALL	B	B
20	500	ALL	B	B
24	600	G16-C8	B	C
		G16-C10	B	B
		G16-C12	B	C
		G16-C10B10	B	B
		G16-C10B12	B	-
		G16-C12B12	-	C
		G16-C12B10B10	B	-
		G16-C12B12B12	B	-
30	750	G16-C8	C	C
		G16-C10	B	B
		G16-C12	B	C
		G16-C10B10	-	C
		G16-C10B12	B	-
		G16-C12B12	C	C
		G16-C12B10B10	B	C
		G16-C12B12B12	B	C
36	900	G16-C10B12	C	-
		G16-C12B12	-	C
		G16-C12B10B10	C	-
		G16-C12B12B12	C	C



Arrangement A



Arrangement B



Arrangement C

Disassembling Actuator

When eccentric valves are mounted in a vertical pipeline, or mounted in a horizontal pipeline with the plug stem horizontal, gravity can cause the plug to swing to a lower position in the valve body when the actuator is removed. To avoid this problem, place the plug in the lowest position before removing the actuator.

1. Discontinue flow and relieve pipeline pressure.



WARNING!

**Accidental operation of power actuator can cause personal injury or equipment damage.
Disconnect and lock out power to actuator before servicing.**

2. Disconnect and lock out the pneumatic power to prevent accidental operation of the actuator. Disconnect the tubing from the cylinder.
3. Remove the extension cap from the actuator housing. On units with booster cylinders, carefully remove the booster cylinder or cylinders.
4. Place the actuator in the open position, then shut off cylinder supply pressure and disconnect the tubing.
5. Remove the nuts and washers from the end of the rack rod.
6. Remove the screws or nuts fastening the cylinder assembly to the housing and carefully remove the cylinder assembly by sliding it away from the actuator until the rack rod clears the actuator housing.
7. If the valve is **4–20" (100–500mm)**:
 - a. Remove lock nut, spring washers, wrenching nut & pointer from the plug stud.
 - b. Proceed to step 9.
8. If the valve is **24–36" (600–900mm)**:
 - a. Loosen lockscrews #1 about 6 to 8 turns and loosen lockscrews #2 about 3 turns. See Figure 4.
 - b. Using a soft hammer, tap the heads of the #1 lockscrews to loosen the keys.
9. Remove the four screws holding the wrenching nut to the gear sector, then remove the stud locknut, spring washers and the wrenching nut with the keys attached.
10. Scribe corresponding lines on the actuator cover and housing, then remove the cover screws and cover from the top of the actuator.
11. Mark the teeth of the rack and gear as shown in Figure 6 and lift the gear sector out of the actuator.
12. Remove the rack from the housing.




Figure 6 – Scribe Marks

DeZURIK

Cylinder Operated G-Series Actuator

Disassembling Actuator *(Continued)*

13. Remove the rack bearing (if noticeable wear to bearing) by driving the pin out of the rack bearing and actuator housing.
14. Scribe corresponding lines on the valve and adapter to be used for alignment during actuator reassembly.



WARNING!

This valve is a pressure vessel. On 4, 5, 6 and 10" (100, 125, 150 and 250mm) valves, the same bolts hold both the actuator and the bonnet.

Removing the bolts on 4, 5, 6 and 10" (100, 125, 150 and 250mm) valves before relieving pipeline pressure can result in personal injury or equipment damage.

Always relieve pipeline pressure before removing the actuator.

15. Remove the screws fastening the adapter to the valve; ensure the pipeline pressure is relieved before removing these screws on **4, 5, 6 and 10" (100, 125, 150 and 250mm)** valves.
16. Lift the rest of the actuator and the adapter off the valve.
17. Remove the screws fastening the adapter to the actuator housing, and separate the two parts.

Reassembling Actuator

Install new bearings and seals in the adapter and cover if necessary. See Figure 7 for proper placement.




Figure 7 – Location of Actuator Seals and Bearings

Reassembling Actuator *(Continued)*

1. Scrape old gasket material from the actuator housing and the adapter, install a new gasket, then fasten the adapter to the actuator housing with the screws.
2. Line up the scribe marks on the valve and adapter made during actuator removal, then set the adapter and housing on the valve.
3. Fasten the adapter to the valve.
4. Drive the pin through the rack bearing and actuator housing (if replacing worn bearing).
5. Apply a liberal amount of grease to the rack teeth and the back of the rack, which will contact the rack bearing, then install the rack in the housing.
6. Apply a liberal amount of grease to the gear sector teeth and journals, then place the gear sector in the housing and carefully align the teeth with the rack as marked during disassembly..

NOTE: It may be necessary to loosen the adapter mounting screws and move the housing a small amount to align the gears. Be sure to retighten the mounting screws after aligning the gears.

7. Install the cylinder/rack rod assembly by sliding the rack rod through the rack then fasten the cylinder to the housing.

NOTE: If the rack rod is not attached to the cylinder, clean the threads of both the rack rod and the cylinder shaft, then apply Loctite to the cylinder shaft threads and screw the rack rod onto the cylinder shaft.

8. Slide the spacer, spring washers and nuts onto the rack rod. See Table E for spring washer placement.
9. Screw one nut onto the rack rod until the spring washers are completely compressed, then loosen the nut just until the washers return to normal shape.
10. Screw the other nut onto the rack rod and tighten the two nuts against each other.
11. Set a new cover gasket on the housing, then install and fasten the top cover on the housing; make sure the scribe marks line up.
12. Slide the pointer and wrenching nut down the plug stud so it rests on top of the gear sector; the pointer should point to indicate the correct valve position.
13. If the valve is **24–36" (600–900mm)**, hold the keys in position when you slide the wrenching nut over the plug stud, and guide the keys into the gear sector and stem slots. Then install the four screws fastening the wrenching nut to the gear sector.
14. Place the spring washers on the plug stud as shown in Figure 5.
15. Screw the lock nut down the plug stud until it is tight and the spring washers are completely compressed, then back the nut off one full turn.
16. If the valve is **24–36" (600–900mm)**, tighten the #2 lockscrews and then the #1 lockscrews to hold the keys in place. Skip this step if the valve is **4–20" (100–500mm)**.
17. Replace the extension cap. On units with booster cylinders, replace the booster cylinder or cylinders.
18. Adjust the open and closed position stops. See "*Position Stops*" section.

Changing Mounting Positions

On **4–20" (100–500mm)** valves, the actuator can be mounted in 30° increments around the valve shaft. 30° position changes require changing the timing between the gear sector and the rack; 60° position changes do not require changing the timing.

On **24–36" (600–900mm)** valves, the actuator can be mounted in 45° increments around the valve shaft. 45° position changes require changing the timing between the gear sector and the rack; 90° position changes do not require changing the timing.

Mounting Actuator in 60° Increments on 4–20" (100–500mm) Valves and 90° Increments on 24–36" (600–900mm) Valves

1. Remove the actuator from the valve. See “*Removing Actuator*” section.



WARNING!

Accidental operation of power actuator can cause personal injury or equipment damage. Disconnect and lock out power to actuator before servicing.

2. Disconnect and lock out the pneumatic power to prevent accidental operation of the actuator.
3. Rotate the actuator into position.
4. Install the actuator on the valve. See “*Installing Actuator*”.

Mounting Actuator in 30° Increments on 4–20" (100–500mm) Valves Only

When eccentric valves are mounted in a vertical pipeline, or mounted in a horizontal pipeline with the plug stem horizontal, gravity can cause the plug to swing to a lower position in the valve body when the actuator is removed. To avoid this problem, place the plug in the lowest position before removing the actuator.

1. Discontinue flow and relieve pipeline pressure.



WARNING!

Accidental operation of power actuator can cause personal injury or equipment damage. Disconnect and lock out power to actuator before servicing.

2. Disconnect and lock out the pneumatic power to prevent accidental operation of the actuator.
3. Remove the lock nut, spring washers, wrenching nut and pointer from the plug stud.
4. Scribe corresponding lines on the actuator cover and housing, then remove the cover screws and cover from the top of the actuator.
5. Mark which teeth of the rack and gear are engaged and lift the gear sector out of the actuator.

Changing Mounting Positions *(Continued)*

6. Remove the screws fastening the adapter to the valve. On the **4, 5, 6 and 10"** (100, 125, 150 and 250mm) valves, these screws also hold the bonnet to the valve body.



WARNING!

This valve is a pressure vessel. On 4, 5, 6 and 10" (100, 125, 150 and 250mm) valves, the same bolts hold both the actuator and the bonnet.

Removing the bolts on 4, 5, 6 and 10" (100, 125, 150 and 250mm) valves before relieving pipeline pressure can result in personal injury or equipment damage.

Always relieve pipeline pressure before removing the actuator.

7. Take out the screws fastening the actuator housing to the adapter.
8. Rotate the adapter on the valve, and the actuator on the adapter until the holes line up and the actuator is in the desired position. Replace all of the screws.
9. Find the tooth that was marked on the gear sector and count over clockwise four teeth on the size 4 and 6 actuators, and five teeth on the size 12 and 16 actuators. This is the tooth that will engage with the marked tooth on the rack. Install the gear sector using the new tooth engagement, and be sure the gear sector fits on the plug stem properly.
10. Set a new cover gasket on the housing, then install and fasten the top cover on the housing; make sure the scribe marks line up.
11. Slide the pointer and wrenching nut down the plug stud so it rests on top of the gear sector; the pointer should point to indicate the correct valve position.
12. Place the spring washers on the plug stud as shown in Figure 5.
13. Screw the lock nut down the plug stud until it is tight and the spring washers are completely compressed, then back the nut off one full turn.
14. Adjust the position stops. See "*Position Stops*" section.

Mounting Actuator in 45° Increments on 24–36" (600–900mm) Valves Only

When eccentric valves are mounted in a vertical pipeline, or mounted in a horizontal pipeline with the plug stem horizontal, gravity can cause the plug to swing to a lower position in the valve body when the actuator is removed. To avoid this problem, place the plug in the lowest position before removing the actuator.

1. Discontinue flow and relieve pipeline pressure.



WARNING!

Accidental operation of power actuator can cause personal injury or equipment damage. Disconnect and lock out power to actuator before servicing.

2. Disconnect and lock out the pneumatic power to prevent accidental operation of the actuator.
3. Loosen lockscrews #1 about 6 to 8 turns. Loosen lockscrews #2 about 3 turns. See Figure 4.
4. Using a soft hammer, tap the heads of the #1 lockscrews to loosen the keys.

Changing Mounting Positions *(Continued)*

5. Remove the four screws that hold the wrenching nut to the gear sector, then remove the stud locknut, spring washers and the wrenching nut with the keys.
6. Scribe corresponding lines on the actuator cover and housing, then remove the cover screws and cover from the top of the actuator.
7. Mark which teeth of the rack and gear are engaged, and lift the gear sector out of the actuator.
8. Remove the screws fastening the adapter to the valve.
9. Remove the screws fastening the actuator housing to the adapter.
10. Rotate the adapter on the valve and the actuator on the adapter until the holes line up and the actuator is in the desired position. Replace all of the screws.
11. Note the tooth that was marked on the gear sector and count clockwise five teeth on the size 16 actuator. This is the tooth that will engage with the marked tooth on the rack. Install the gear sector using the new tooth engagement, and be sure the keyways in the gear sector match the keyways in the plug stem.
12. Set a new cover gasket on the housing, then install the top cover on the housing, making sure the scribe marks line up.
13. Hold the keys in position and slide the wrenching nut over the plug stud, then guide the keys into the gear sector and stem slots.
14. Install the four screws fastening the wrenching nut to the gear sector.
15. Place the spring washers on the plug stud as shown in Figure 5.
16. Screw the lock nut down the plug stud until it is tight and the spring washers are completely compressed, then back the nut off one full turn.
17. Tighten the #2 lockscrews, and then the #1 lockscrews to hold the keys in place.
18. Adjust the position stops—see “*Position Stops*” section.

Troubleshooting

Condition	Possible Cause	Corrective Action
Actuator closes to wrong position	Closed position stop is set incorrectly	Adjust closed position stop. See <i>Adjusting Position Stops</i> section
Actuator opens to wrong position	Open position stop is set incorrectly	Adjust open position stop. See <i>Adjusting Position Stops</i> section
Actuator will not fully operate valve	Cylinder pressure is low	Increase cylinder pressure. Do not exceed 100 psi (69 kPa).
	Piston seal in cylinder is leaking	Replace piston seal(s). See Cylinder instructions.
	Pipeline obstruction in valve is preventing closure	Remove obstruction
Actuator rotates wrong direction	Air connections to cylinder are incorrect	Reverse air connections to cylinder

Limited Warranty

DeZURIK, Inc. ("Seller") manufactured products, auxiliaries and parts thereof that we manufacture for a period of twenty-four (24) months from date of shipment from Seller's factory, are warranted to the original purchaser only against defective workmanship and material, but only if properly stored, installed, operated, and serviced in accordance with Seller's recommendations and instructions.

For items proven to be defective within the warranty period, your exclusive remedy under this limited warranty is repair or replacement of the defective item, at Seller's option, FCA Incoterms 2020 Seller's facility with removal, transportation, and installation at your cost.

Products or parts manufactured by others but furnished by Seller are not covered by this limited warranty. Seller may provide repair or replacement for other's products or parts only to the extent provided in and honored by the original manufacturer's warranty to Seller, in each case subject to the limitations contained in the original manufacturer's warranty.

No claim for transportation, labor, or special or consequential damages or any other loss, cost or damage is being provided in this limited warranty. You shall be solely responsible for determining suitability for use and in no event shall Seller be liable in this respect.

This limited warranty does not warrant that any Seller product or part is resistant to corrosion, erosion, abrasion or other sources of failure, nor does Seller warrant a minimum length of service.

Your failure to give written notice to us of any alleged defect under this warranty within twenty (20) days of its discovery, or attempts by someone other than Seller or its authorized representatives to remedy the alleged defects therein, or failure to return product or parts for repair or replacement as herein provided, or failure to store, install, or operate said products and parts according to the recommendations and instructions furnished by Seller shall be a waiver by you of all rights under this limited warranty.

This limited warranty is voided by any misuse, modification, abuse or alteration of Seller's product or part, accident, fire, flood or other Act of God, or your failure to pay entire contract price when due.

The foregoing limited warranty shall be null and void if, after shipment from our factory, the item is modified in any way or a component of another manufacturer, such as but not limited to; an actuator is attached to the item by anyone other than a Seller factory authorized service personnel.

All orders accepted shall be deemed accepted subject to this limited warranty, which shall be exclusive of any other or previous warranty, and this shall be the only effective guarantee or warranty binding on Seller, despite anything to the contrary contained in the purchase order or represented by any agent or employee of Seller in writing or otherwise, notwithstanding, including but not limited to implied warranties.

THE FOREGOING REPAIR AND REPLACEMENT LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, OBLIGATIONS AND LIABILITIES, INCLUDING, BUT NOT LIMITED TO, ALL WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR OF MERCHANTABILITY OR OTHERWISE, EXPRESSED OR IMPLIED IN FACT OR BY LAW, AND STATE SELLER'S ENTIRE AND EXCLUSIVE LIABILITY AND YOUR EXCLUSIVE REMEDY FOR ANY CLAIM IN CONNECTION WITH THE SALE AND FURNISHING OF SERVICES, GOODS OR PARTS, THEIR DESIGN, SUITABILITY FOR USE, INSTALLATION OR OPERATIONS. NEITHER ANY PERFORMANCE OR OTHER CONDUCT, NOR ANY ORAL OR WRITTEN INFORMATION, STATEMENT, OR ADVICE PREPARED BY SELLER OR ANY OF OUR EMPLOYEES OR AGENTS WILL CREATE A WARRANTY, OR IN ANY WAY INCREASE THE SCOPE OR DURATION OF THE LIMITED WARRANTY.

Disclaimer

Metric fasteners should not be used with ASME Class 150/300 bolt holes and flange bolt patterns. If you use metric fasteners with ASME Class 150/300 bolt holes and flange bolt patterns, it may lead to product failure, injury, and loss of life. DeZURIK Inc. disclaims all liability associated with the use of metric fasteners with ASME Class 150/300 bolt holes and flange patterns, including but not limited to personal injury, loss of life, loss of product, production time, equipment, property damage, lost profits, consequential damages of any kind and environment damage and/or cleanup. Use of metric fasteners with ASME Class 150/300 bolt holes and flange bolt patterns is a misuse that voids all warranties and contractual assurances. If you use metric fasteners with ASME Class 150/300 bolt holes and flange bolt patterns, you do so at your sole risk and any liability associated with such use shall not be the responsibility of DeZURIK, Inc. In addition to the foregoing, DeZURIK's Manufacturer's Conditions apply.

Limitation of Liability

IN NO EVENT SHALL SELLER BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, PUNITIVE, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO; DAMAGE TO OR LOSS OF OTHER PROPERTY OR EQUIPMENT, BUSINESS INTERRUPTION, COST OF SUBSTITUTE PRODUCTS, LOSS OF TIME, LOSS OF PROFITS OR REVENUE, COST OF CAPITAL, LOSS OF USE, OR DIMINUTION IN VALUE) WHATSOEVER, AND SELLER'S LIABILITY, UNDER NO CIRCUMSTANCES, WILL EXCEED THE CONTRACT PRICE FOR THE GOODS AND/OR SERVICES FOR WHICH LIABILITY IS CLAIMED. ANY ACTION FOR BREACH OF CONTRACT BY YOU, OTHER THAN RIGHTS RESPECTING OUR LIMITED WARRANTY DESCRIBED ABOVE, MUST BE COMMENCED WITHIN 12 MONTHS AFTER THE DATE OF SALE.

Sales and Service

For information about our worldwide locations, approvals, certifications and local representative:

Web site: www.dezurik.com E-Mail: info@dezurik.com



250 Riverside Ave. N., Sartell, MN 56377 • Phone: 320-259-2000 • Fax: 320-259-2227

DeZURIK, Inc. reserves the right to incorporate our latest design and material changes without notice or obligation.

Design features, materials of construction and dimensional data, as described in this manual, are provided for your information only and should not be relied upon unless confirmed in writing by DeZURIK, Inc. Certified drawings are available upon request.